

Table 1: P0 Numbers (Sheet 1 of 2)

P0 Number R23	Title	Format	P0 Number R22	P0 Number R21b	P0 Number R21A	P0 Number R20	R19.18	R19.14	R19.10
P0868057	Library navigator	Binder	P0842656	P0820897	P0813952	P0800513	P0748302	P0747107	None
P0868059	System installation and maintenance guide	Binder	P0842658	P0820899	P0813966	P0800514	P0748297	P0746456	P0744195
P0868060	System and software upgrade guide	Binder	P0842659	P0820900	P0813967	P0800515	P0748298	P0746457	P0744196
P0868058	System planning and engineering guide	Binder	P0842657	P0820898	P0813968	P0800516	P0748299	P0746458	P0744197
P0868061	Remote peripheral equipment	Binder	P0842660	P0820901	P0813969	P0800517	None	None	None
P0868062	X11 software fea- tures guide	Binder	P0842661	P0820902	P0813953	P0800518	P0748300	P0746459	P0744198
P0868064	X11 system manage- ment overview, appli- cations, and security	Binder	P0842662	P0820903	P0813954	P0800519	P0746460	P0746460	P0744199
P0868065	X11 input/ output guide	Binder	P0842663	P0820904	P0813955	P0800520	P0748301	P0746461	P0744200
P0868066	X11 data features	Binder	P0820905	P0820905	P0800521	P0800521	P0746462	P0746462	P0744201
P0868067	X11 hospitality fea- tures	Binder	P0849011	P0820906	P0800522	P0800522	P0746463	P0746463	P0744202
P0868068	Networking features	Binder	P0842664	P0820907	P0813956	P0800523	P0746464	P0746464	P0744203
P0868069	ISDN Basic Rate Inter- face	Binder	P0842665	P0820908	P0813957	P0800524	P0746465	P0746465	P0744204
P0868071	Automatic call distri- bution reference guide	Binder	P0842666	P0820909	P0813958	P0800525	P0746466	P0746466	P0744205
P0830301	Meridian COMPANION	Binder	P0830301	P0809892	P0809892	P0800368	None	None	None
P0800553	Power monitor/ com- mon equipment auxil- iary shelves 553-3001-570	Stand- alone	P0800553	P0800553	P0800553	P0800553			

Table 1: P0 Numbers (Sheet 2 of 2)

P0 Number R23	Title	Format	P0 Number R22	P0 Number R21b	P0 Number R21A	P0 Number R20	R19.18	R19.14	R19.10
P0800554	NT6D82 Power Sys- tem Description, instal- lation, and maintenance 553-3001-110	Stand- alone	P0800554	P0800554	P0800554	P0800554			
P0813970	XN, XT Network Mod- ule expansion 553-2201-156	Stand- alone	P0813970	P0813970	P0813970	P0800555			
P0868046	Software conversion procedures 553-2001-320	Stand- alone	P0842841	P0813959	P0813959	P0800556			
P0802241	AUTOVON Reference guide 553-2661-110	Stand- alone	P0802241	P0802241	P0802241	P0802241			
	System Upgrade Guide, Canada and CALA			P0813965					
P0868046	Software conversion procedures	Spiral	P0842841	P0820912	P0813959	P0800556			
P0868047	X11 Feature Document	Spiral	P0842842	P0820913	P0813960	P0800557			
P0868051	X11 system messages	Spiral	P0842845	P0820916	P0813961	P0800558			
P0868049	X11 maintenance pro- grams	Spiral	P0842843	P0820914	P0813962	P0800559			
P0868048	X11 system manage- ment overview, appli- cations, and security	Spiral	P0849012	P0820917	P0813963	P0800560			
P0868044	System installation and maintenace	Spiral	P0842839	P0820910	P0813971	P0800561			
P0868045	Switch settings, cad and product compati- bility	Spiral	P0842840	P0820911	P0813972	P0800562			
P0868050	X11 administration programs and feature implementation	Spiral	P0842844	P0820915	P0813964	P0800600			